

Piper Saratoga PA-32R-301T

Normal and Emergency Checklists

SPEED REFERENCE

VNE	191	KIAS
VNO	160	KIAS
Vso	63	KIAS
Vs1	67	KIAS
Vr	88	KIAS
VR SHORT FIELD	84	KIAS
Vx	84	KIAS
VY GEAR UP, FLAPS UP	93	KIAS
VA (3600)	134	KIAS
Vfe Vlo	110	KIAS
VLE	132	KIAS
BEST GLIDE	83	KIAS

ATC LIGHT GUN SIGNALS

Color & Type	On the Ground	In Flight
Steady Green	Cleared for takeoff	Cleared to land
Flashing Green	Cleared to taxi	Return for landing
Steady Red	STOP	Give way, continue circling
Flashing Red	Taxi clear of the runway	Airport unsafe, do not land
Flashing White	Return to starting point	N/A
Alt. Red / Green	Exercise extreme caution	Exercise extreme caution

PREFLIGHT INSPECTION - COCKPIT

Required Documents	AVAILABLE
Airworthiness Certificate	
R egistration	
R adio License (int'l)	
O perating Reference (POH)	
Weight & Balance	
Maintenance Status	CHECKED
Hobbs & Tach Meters	CHECKED
Control Lock	REMOVED
Landing Gear Selector	CHECK DOWN
Radio Master	OFF
Circuit Breakers	CHECK IN
Propeller Area	CLEAR
Magneto Switches	OFF
BATT Master	ON
Fuel Quantity	CHECKED
Annunciator Panel	PUSH TO TEST
Pitot Heat	CHECK
Flaps	EXTEND FULL
All Lights	ON & CHECK
All Lights (except beacon)	OFF
BATT Master	OFF

PREFLIGHT INSPECTION – EXTERNAL

RIGHT WING

Flap & Aileron Wing Tip & Leading Edge Tie Down Fuel Level Fuel Cap Fuel Strainer Strut, Tire and Brake **NOSE** Engine Cooling Air Inlets Propeller & Spinner Baggage Door CHECKED CHECKED REMOVED CHECKED SECURED CHECKED CHECKED

CHECKED SECURED

Air Filter Nose Wheel & Strut Engine Oil Windshield	CLEAR CHECKED 9-10 QTS CHECKED
LEFT WING	
Leading Edge & Wing Tip	CHECKED
Fuel Level	CHECKED
Fuel Cap	SECURED
Fuel Strainer	CHECKED
Stall Warning Openings	CLEAR
Pitot Tube Cover	REMOVED
Pitot Tube	CHECKED
Tie Down	REMOVED
Aileron and Flap	CHECKED
Strut, Tire and Brake	CHECKED
EMPENNAGE	
Window Shades	OPEN
Cabin Door	SECURED
Tie Down	REMOVED
Stabilator & Trim Tab	CHECKED

BEFORE STARTING ENGINE			
Preflig	ht Inspection	COMPLETE	
Seat P	osition	ADJUST	
Seatbe	elts	SECURED	
Doors		CLOSED	
Passer	igers	BRIEF	
1) Seatbelts / shoulder harnesses			
2)	2) Personal electronic devices off		
3) Air vents / comfort			
4) Fire extinguisher location / operation			
5) Door operation			
6)	Emergency procedures & egress		
Parkin	g Brake	PULL ON	
Flaps		UP	
Mixture CUT OFF		CUT OFF	
Throttle IDLE			

STARTING ENGINE

Fuel Tank Selector	L or R TANK	
Propeller Area	CLEAR	
BATT Master	ON	
FIN Strobe	ON	
NORMAL START		
Mixture	CUT OFF	
Throttle	1/4" OPEN	
ALTR Switch	ON	
Magneto Switches	BOTH ON	
Fuel Pump	ON	
Prime	IF REQUIRED	
Mixture	FULL RICH	
Mixture	CUT OFF	
Starter Button	ENGAGE	
Mixture	ADVANCE	
Throttle	1200 RPM	
Oil Pressure	CHECKED	
Fuel Pump	OFF	
Mixture	LEAN	
FLOODED START		
Throttle	FULL FORWARD	
Master Switch	ON	
ALTR Switch	ON	
Magneto Switches	BOTH ON	
Fuel Pump	OFF	
Mixture	CUT OFF	
Starter Button	ENGAGE	
Mixture	ADVANCE RICH	
Throttle	RETARD	
Oil Pressure	CHECK	
Fuel Pump	OFF	

BEFORE TAXI

Electri	cal System	VERIFY AMPS/VOLTS
PFD M	aster	ON
Radio	Master	ON
AP Ma	ster	ON
Engine	e Gauges	CHECK GREEN
GPS D	atabase	VERIFY DATE
Fuel Q	uantity	CHECK & RESET
Radios	5	SET & CHECK
FMS &	Weather	SETUP / OBTAIN
Altime	eter (PFD & Dial)	SET
	ilot Altimeter (Baro)	SET
Transp	onder	CHECK ALT
-	G650s	CHECK NO RED X's
Flight Instruments		CHECK & BRIEF
1)	Airspeed, ZERO	
2) Attitude Indicator, IN-LINE WITH HORIZON		
3) Altimeter, WITHIN 75FT OF FIELD ELEVATION		
4) Turn coordinator, LEVEL AND BALL CENTERED		
	5) Vertical speed indicator, ZERO	
	Heading indicator, CHEC	
Taxi Cl	earance	OBTAIN IF REQUIRED
Taxi Li	ght	ON
NAV Light ON		
Parkin	g Brake	RELEASED
Taxi Area		CLEAR
Brakes	5	TEST

Parking Brake	OFF (RUN UP)
Cabin Doors & Windows	CLOSED
Seatbelts	SECURED
Autopilot	TEST
1) Autopilot - ENGAGE	
2) Flight Controls – VERIF	YOVERPOWER
 Autopilot Disconnect – 	VERIFY
Elevator Trim	SET TO TAKEOFF
Flight Controls	FREE & CORRECT
Fuel Pump	ON
Fuel Tank Selector	CHANGE TANK
Mixture	RICH
Throttle	2000 RPM
Magneto Check	R-BOTH-L-BOTH
Max RPM drop of 175, max dif	
Propeller Feather Check	Drop RPM / Rise MP
Propeller Feather Check	OP CHECKED
Propeller Feather Check	NO OIL LEAKS
Engine Indicators	CHECK GREEN
Ammeters and Voltmeters	CHECK
Fuel Pump	OFF
Fuel Flow	CHECK
Throttle	CHECK IDLE
Throttle	1200 RPM
Clearance	OBTAIN IF REQUIRED
FMS / GPS Flight Plan	CHECK & SET
Altitude Select	SET
Heading	SET
Transponder	VFR or CODE

Depart	ture Briefing	COMPLETE	
This will be a VFR / IFR departure to			
(Wh	(Who) will be performing the takeoff.		
Туре	Type of takeoff to be performed, flaps set.		
Revi	Review V speeds (VR, Vx, and Vy/Climb).		
Run	ways in use, planned takeoff rur	nway.	
Review takeoff distances, abort if not off by			
Review positive exchange of flight controls.			
Review emergency procedures:			
1)	Any malfunction before VR:		
	Idle power, abort straight ahe	ad	
2)	Any malfunction after VR with	runway:	
Abort / land straight ahead			
3)	Engine malfunction after VR wi	thout runway and	
	below 500ft AGL:		
	Select suitable landing area al	head, fuel	
off, mixture cut off, master off, mags off,			
	release door latch.		
4)	Engine malfunction above 500	ft AGL:	
Best glide airspeed of 83 KIAS, select			
	landing area, possible return	to airport.	
Parkin	g Brake	RELEASED	

NORMAL TAKEOFF

Trim	SET
Propeller	FULL FORWARD
Mixture	FULL RICH
Flaps	UP / 10° IF REQ'D
Doors & Window	CLOSED
Air Conditioning	OFF
Landing Light	ON
Strobe Lights	ON
Fuel Pump	ON
Traffic	FINAL CLEAR
Departure Runway	VERIFY
Throttle	FULL – 38" MAX
Airspeed Indicator	VERIFY
Engine Gauges	CHECK GREEN
Rotate VR	88 KIAS
Airspeed Vy	93 KIAS
Landing Gear	UP

CLIMB –	500FT AGL
Airspeed Vy	105 KIAS
Flaps	UP
Engine Gauges	CHECK GREEN
Throttle	36" MP
Propeller	2400 RPM

(CRUISE
Fuel Pump	OFF
Taxi Light	OFF
Landing Light	PULSE
Throttle	SET 22-31" MP
Propeller	SET 2200-2400
Mixture	LEAN FOR 1625 TIT
FMS / GPS	REVIEW

CRUISE POWER SETTINGS

2200RPM – 25" MP – 12.5GPH 2200RPM – 28" MP – 14.5GPH 2300RPM – 30" MP – 16.5GPH 2400RPM – 33" MP – 20.0GPH

PRE-MANEUVER CHECKLIST

Emergency Landing Area	CONFIRM
Seatbelts	SECURED
Fuel Tank Selector	CHANGE
Propeller	FULL FORWARD
Mixture	AS REQUIRED
Landing Light	PULSE
Fuel Pump	ON
Clearing Turns	PERFORM

DESCENT		
Weather	OBTAIN	
Seatbelts	SECURED	
Mixture	ADJUST	
Engine Cooling	CHECK JPI CLD°	
Altimeters (2 + AP)	SET	
ALT Select	SET	
Instruments / Radios	SET	
Approach / Pattern Entry	BRIEF	
1) Approach Name / Airport		
2) Frequency / Course		
Minimums / Airport and TDZE Elevations		
4) Missed Procedure / MSA		
5) Notes		
6) Highest Obstacle / Terrain Review		
7) Lighting		
8) Crosswind Component		
9) Runway Length Available		
10) Airport Diagram		
11) Destination on Field / Taxi Route	2	
8		

BEFORE LANDING

Seatbelts	SECURED
Fuel Tank Selector	CHANGE
Landing Gear (<132 KIAS)	DOWN
Mixture	RICH
Propeller	FULL FORWARD
Flaps (<110 KIAS)	SET 10°
Landing Light	ON
Taxi Light	ON
Fuel Pump	ON

LANDING	
Autopilot	OFF
Air Conditioning	CHECK OFF
Airspeed	95 KIAS
Flaps	SET 25°
Airspeed	85 KIAS
Flaps	SET 40°

GO AROUND		
Throttle	FULL	
Airspeed	93 KIAS	
Flaps	SET 25°	
Positive Climb Rate – Landing Gear	UP	
Flaps	SET 10°	
Above 500 AGL		
Flaps	UP	
Airspeed	105 KIAS	

AFTER LANDING

Fuel Pump	OFF
Strobe Lights	FIN STROBE
Taxi Light	ON
Landing Lights	OFF
Flaps	UP
Mixture	LEAN

SECURING AIRCRAFT		
Parking Brake	SET	
Throttle	IDLE	
Air Conditioning	OFF	
AP Master Switch	OFF	
Radio Master	OFF	
PFD Master	OFF	
Mixture	CUT OFF	
Magneto Switches	OFF	
BATT Master Switch	OFF	
Taxi Light	OFF	
FIN Strobe	OFF	
Control Lock	INSTALL	
Window	CLOSED	
Pitot Tube Cover	INSTALL	
Tie Downs	INSTALL	
Cowl Plugs	INSTALL	
Flight Plan	CLOSED	

FUEL TANK CHANGE

Fuel Pump
Fuel Tank Selector
Fuel Flow
Fuel Pump

ON CHANGE CHECK OFF

ENGINE FIRE DURING START		
Ignition	HOLD BUTTON	
IF ENGINE STARTS:		
Mixture	CUT OFF	
Throttle	FULL FORWARD	
Fuel Pump	OFF	
Fuel Tank Selector	OFF	
Ignition	OFF	
IF ENGINE DOES NOT STA	RT:	
Ignition	HOLD BUTTON	
Mixture	CUT OFF	
Throttle	FULL FORWARD	
Fuel Pump Switch	OFF	
Ignition Switch	RELEASE	
Master Switch	OFF	
Fire Extinguisher	OBTAIN	
Aircraft	EVACUATE	
Fire	EXTINGUISH	

ENGINE FAILURE DURIN	NG TAKEOFF
Throttle	IDLE
Brakes	APPLY
Mixture	CUT OFF
Magneto Switches	OFF
MasterSwitch	OFF

ENGINE FAILURE AFTER TAKEOFF		
Airspeed	BEST GLIDE	
Flaps Up	83 KIAS	
Flaps 10	64 KIAS	
Mixture	CHECK RICH	
Propeller	FULL FORWARI	
Fuel Pump	CHECK ON	
Fuel Tank Selector	CHANGE	
Magnetos Switches	CHECK ON	
Landing Gear	DOWN	
Flaps	AS REQUIRED	
Alternate Air	OPEN	
Cabin Door	UNLATCH	
Land	STRAIGHT AHEAD	

ENGINE FAILURE DURIN	IG FLIGHT
Airspeed – Best Glide	83 KIAS
Fuel Pump	ON
Mixture	RICH
Fuel Tank Selector	CHANGE
Alternate Air	OPEN
Engine Gauges	CHECK
Air Conditioning	OFF
Magneto Switches	CHECK ON
Ignition Switch (If Prop Stopped)	HOLD

POWER OFF EMERGENCY LANDING

Airspeed
Flaps Up
Throttle
Propeller
Mixture
Magneto Switches
ALT Switch
Fuel Tank Selector
Radio Call 121.5
Transponder
Seats & Seat Belts
Landing Gear
Flaps
BATT Master
Doors

83 KIAS IDLE FULL FORWARD CUT OFF OFF OFF MAY DAY 7700 SECURE DOWN AS REQUIRED OFF UNLATCHED

ENGINE FIRE IN FLIGHT		
Fuel Tank Selector	OFF	
Throttle	IDLE	
Mixture	CUT OFF	
Fuel Pump	OFF	
Cabin Heat and Air	OFF	
BATT Master	OFF	
Cabin Vents	OPEN	
Airspeed	100+ KIAS	
Emergency Landing	EXECUTE	

CABIN FIRE	IN FLIGHT
BATT Master	OFF
ALT Switch	OFF
Cabin Vents	CLOSED
Cabin Heat and Air	OFF
Fire Extinguisher	ACTIVATE
Cabin	VENTILATE

ELECTRICAL FIRE IN FLIGHT

BATT Master	OFF	
Cabin Vents	CLOSED	
Cabin Heat and Air	OFF	
Fire Extinguisher	ACTIVATE	
Radio Switch	OFF	
Electrical Switches	OFF	
Cabin	VENTILATE	
IF FIRE IS OUT AND ELECTRICAL IS NEEDED:		
Circuit Breakers	CHECK	
BATT Master	ON	
Radio Switches	OFF	
ALT Switch	ON	

WI	ING FIRE
Landing Light	OFF
NAV Lights	OFF
Strobe Lights	OFF
Pitot Heat	OFF
Side Slip (fire away)	EXECUTE
Emergency Landing	EXECUTE

ICING

The Piper Saratoga is not equipped for flight into known icing. If icing is encountered, you should make a level 180° turn to exit. Pitot Heat ON

Pitot Heat	ON	
Cabin Heat	ON FULL	
Defroster	OPEN	
Cabin Air	ADJUST	
Throttle	INCREASE	
Stall speed increases with ice bui	ldup, plan approach	
speed at 85+ KIAS with ice buildup.		
Flaps	UP	
Landing	EXECUTE	

PROPELLER OVERSPEED

Throttle Oil Pressure Propeller Airspeed Throttle REDUCE CHECK REDUCE REDUCE UNDER 2700 RPM

EMERGENCY GEAR EXTENSION

BATT Master	CHECK ON	
ALT Switch	CHECK ON	
Circuit Breakers	CHECK	
Light Dimming Switch	CHECK DAY	
Gear Indicator Bulbs	PRESS TO CHECK	
Annunciator Switch	TEST	
If Landing Gear Does No	t Check Down:	
Airspeed	< 90 KIAS	
Landing Gear Selector	DOWN	
If Landing Gear Still Doe	s Not Check Down:	
Emergency Gear Pump	PULL CIRCUIT BREAKER	
Emergency Gear Knob	PULL OUT	
Pull emergency gear knob while fish-trailing airplane.		
Approx. 10 seconds to be down and locked.		
If electrical power has been lost, landing gear must be		
extended by pulling Emergency Gear Knob – position lights		
will not illuminate.		

AMMETER EXCESSIVE CHARGE

Ammeter Full Scale	CHECK
ALTN Switch	OFF
Non-Essential Electrical	OFF
Land	ASAP